























RIGGING UP

Check for overhead obstru HIGH VOLTAGE LINE.

Raising mast to vertical pos

Make sure the foundation Run leveling jacks and o

Level the rig for side-to-s Remove any mast tie-dol

Check hydraulic oil level.

Make sure all guys and w C While raising:

Keep block positioned in it Continue to make sure all

D Before telescoping:

Check to ensure that all wir Check that the tubing platfo

. Continue to see that all wire If ram stabilizers are provide

Visually inspect to see that the transfer to bottom section.

4. All guy lines are securely and

5. All jacks and outriggers should

RIGGING DOWN

Telescoping top section down: Before telescoping, make sure

2. If ram stabilizers are provided

Ram stabilizer remains around 2. All wirelines remain free and cli

Racking platform and rodman p

C Lowering mast to horizontal position Before lowering, make sure air i

2. Traveling block is positioned at

Mast is unlocked from its base s

4. Watch and make sure that the ra

5. Keep traveling block positioned

Grease crown sheave daily.

Grease catline sheaves and tong counterwi Grease automatic folding sheaves each time Oil all hinge points each time hinge is move The hinge points include tilt ram pivots top a monkey board.

Coat ail fixed pins with grease to protect aga

 All sheaves are equipped with green clean chassis lube.

Use lightweight lubricating oil app



















MODEL 572RSL4025

SERIAL WA-554264-1106

TYPE RSL

FRAME ENCL.

1800

INS.CLASS H1
FIELD AMPS 2.2

HZ 60 PF 0.8 AMB. 40 °C RISE BY RES. 80 °C FIELD DLT 48 C

AMPS 571
-STANDBY SERVICEVOLTS

KVA DRIVE BEARING AMPS

REGULATOR NO. DVR2000E

EXCITER BEARING A-7812R-80 PMG 180 PMG 300

GREASING INSTRUCTIONS ---LUBRICATE GENERATOR EVERY 5600 OPERATING HOURS OR ANNUALLY WITH 2.6 CUBIC INCHES OF EXXON POLYREX EM OR EQUIVALENT GREASE WITH A TEMPERATURE RANGE OF -30 °C TO 175 °C

















































